

E

Quemadores de gasóleo

Instrucciones de Instalación,
Montaje y Funcionamiento
para el **INSTALADOR**

D

Ölbrenner

Installations-, Montage-
und Betriebsanleitung
für den **INSTALLATEUR**

GB

Oil burners

Installation, Assembly,
and Operating Instructions
for the **INSTALLER**

I

Bruciatori di gasolio

Istruzioni per l'Installazione,
il Montaggio e il Funzionamento
per l'**INSTALLATORE**

F


Brûleurs fioul

Instructions d'Installation,
de Montage et de Fonctionnement
pour l'**INSTALLATEUR**

P

Queimadores de gasóleo

Instruções de Instalação,
Montagem e Funcionamento
para o **INSTALADOR**



E	INDICE	página
1.	CARACTERÍSTICAS PRINCIPALES	18
2.	DESCRIPCIÓN DEL QUEMADOR	18
2.1	Forma de suministro	18
3.	DATOS TÉCNICOS	4
3.1	Datos técnicos	4
3.2	Dimensiones	6
3.3	Campo de trabajo	7
4.	INSTALACIÓN	18
4.1	Fijación a la caldera	18
4.2	Alimentación del combustible	18
4.3	Instalación hidráulica	18
4.4	Conexiones eléctricas	18
4.5	Regulación de los electrodos	18
5.	FUNCIONAMIENTO	19
	QUEMADORES CRONO 2-3-5-10 y 15-L	
5.1	Regulación de la combustión	19
5.2	Boquillas aconsejadas	19
5.3	Presión de la bomba	19
5.4	Reg. del cabezal de combustión (CRONO 5-10 y 15-L) ..	19
5.5	Regulación del registro del aire	19
5.6	Precaentamiento del combustible (CRONO 2-3 y 5-L) ..	19
	QUEMADOR CRONO 20-L	
5.7	Regulación de la combustión	19
5.8	Boquillas aconsejadas	19
5.9	Regulación del cabezal de combustión	19
5.10	Presión bomba y caudal de aire	19
6.	CICLO DE PUESTA EN MARCHA	20
7.	MANTENIMIENTO	21
8.	ANOMALÍAS / SOLUCIONES	21

F	SOMMAIRE	page
1.	PRINCIPALES CARACTÉRISTIQUES	20
2.	DESCRIPTION BRÛLEUR	20
2.1	Matériel fourni	20
3.	Données techniques	4
3.1	Données techniques	4
3.2	Dimensions	6
3.3	Plages de travail	7
4.	INSTALLATION	26
4.1	Fixation à la chaudière	26
4.2	Alimentation du combustible	26
4.3	Installation hydraulique	26
4.4	Raccordements électriques	26
4.5	Réglage des électrodes	26
5.	FONCTIONNEMENT	27
	BRÛLEURS CRONO 2-3-5-10 Y 15-L	
5.1	Réglage de la combustion	27
5.2	Gicleurs conseillés	27
5.3	Pression pompe	27
5.4	Réglage tête de combustion (CRONO 5-10 y 15-L) ..	27
5.5	Réglage volet d'air	27
5.6	Réchauffage du combustible (CRONO 2-3 y 5-L) ..	27
	BRÛLEUR CRONO 20-L	
5.7	Réglage de la combustion	27
5.8	Gicleurs conseillés	27
5.9	Réglage tête de combustion	27
5.10	Pression pompe et débit air	27
6.	PROGRAMMES DE MISE EN MARCHÉ	20
7.	ENTRETIEN	21
8.	PANNES / REMÈDES	21


GB	INDEX	page
1.	MAIN FEATURES	22
2.	BURNER DESCRIPTION	22
2.1	Burner equipment	22
3.	TECHNICAL DATA	4
3.1	Technical data	4
3.2	Overall dimensions	6
3.3	Working fields	7
4.	INSTALLATION	22
4.1	Boiler fixing	22
4.2	Fuel supply	22
4.3	Hydraulic systems	22
4.4	Electrical wiring	22
4.5	Electrodes settings	22
5.	WORKING	23
	BURNERS CRONO 2-3-5-10 y 15-L	
5.1	Combustion adjustment	23
5.2	Recommended nozzles	23
5.3	Pump pressure	23
5.4	Combustion head setting (CRONO 5-10 y 15-L) ..	23
5.5	Air damper adjustment	23
5.6	Fuel heating (CRONO 2-3 y 5-L)	23
	BURNER CRONO 20-L	
5.7	Combustion adjustment	19
5.8	Recommended nozzles	19
5.9	Combustion head setting	19
5.10	Pump pressure and air output	19
6.	BURNER START-UP CYCLE	20
7.	MAINTENANCE	21
8.	FAULTS / SOLUTIONS	21

D	INHALT	Seite
1.	HAUPTMERKMALE	20
2.	BESCHREIBUNG DES BRENNERS	20
2.1	Mitgeliefertes zubehör	20
3.	TECHNISCHE MERKMALE	5
3.1	Technische Daten	5
3.2	Abmessungen	6
3.3	Arbeitsfelder	7
4.	INSTALLATION	30
4.1	Brennerrnontage	30
4.2	Brennstoffversorgung	30
4.3	Ölversorgungsanlage	30
4.4	Elektrisches Verdrahtungsschema	30
4.5	Elektrodeinstellung	31
5.	BETRIEB	31
	BRENNER CRONO 2-3-5-10 Y 15-L	
5.1	Einstellung der Brennerleistung	31
5.2	Empfohlene Düsen	31
5.3	Pumpendruck	31
5.4	Brennkopfeinstellung (CRONO 5-10 y 15-L) ..	31
5.5	Luftklappeneinstellung	31
5.6	Vorwärmung des Heizöl-EL (CRONO 2-3 y 5-L) ..	31
	BRENNER CRONO 20-L	
5.7	Einstellung der Brennerleistung	31
5.8	Empfohlene Düsen	31
5.9	Brennkopfeinstellung	31
5.10	Pumpendruck and Luftdurchsatz	32
6.	BETRIEBSABLÄUFE	32
7.	WARTUNG	33
8.	STÖRUNGEN / ABHILFEN	33


I	INDICE	pagina
1.	CARATTERISTICHE PRINCIPALI	34
2.	DESCRIZIONE DEL BRUCIATORE	34
2.1	Materiale a corredo	34
3.	DATI TECNICI	5
3.1	Dati tecnici	5
3.2	Dimensioni	6
3.3	Campi di lavoro	7
4.	INSTALLAZIONE	34
4.1	Fissaggio alla caldaia	34
4.2	Alimentazione del combustibile	34
4.3	Impianti idraulici	34
4.4	Collegamenti elettrici	34
4.5	Regolazione elettrodi	34
5.	FUNZIONAMENTO	35
	BRUCIATORI CRONO 2-3-5-10 e 15-L	
5.1	Regolazione della combustione	35
5.2	Ugelli consigliati	35
5.3	Pressione della pompa	35
5.4	Regolazione testa di combustione (CRONO 5-10 e 15-L)	35
5.5	Regolazione serranda aria	35
5.6	Riscaldamento del combustibile (CRONO 2-3 e 5-L)	35
	BRUCIATORE CRONO 20-L	
5.7	Regolazione della combustione	35
5.8	Ugelli consigliati	35
5.9	Regolazione testa di combustione	35
5.10	Pressione pompa e portata aria	35
6.	PROGRAMMI DI AVVIAMENTO	36
7.	MANUTENZIONE	37
8.	ANOMALIE / RIMEDI	37

P	ÍNDICE	página
1.	CARACTERÍSTICAS PRINCIPAIS	38
2.	DESCRIÇÃO DO QUEIMADOR	38
2.1	Material fornecido	38
3.	DADOS TÉCNICOS	5
3.1	Dados técnicos	5
3.2	Dimensões	6
3.3	Campo de trabalho	7
4.	INSTALAÇÃO	38
4.1	Fixação à caldeira	38
4.2	Alimentação de combustível	38
4.3	Instalação hidráulica	38
4.4	Ligações eléctricas	38
4.5	Regulação dos eléctrodos	38
5.	FUNIONAMENTO	39
	QUEIMADORES CRONO 2, 3, 5, 10 e 15-L	
5.1	Regulação da combustão	39
5.2	Boquilhas aconselhadas	39
5.3	Pressão da bomba	39
5.4	Regulação do cabeçal de combustão (CRONO 5, 10 e 15-L)	39
5.5	Regulação do registro de ar	39
5.6	Préaquecimento do combustível (CRONO 2, 3 e 5-L)	39
	QUEIMADOR CRONO 20-L	
5.7	Regulação da combustão	39
5.8	Boquilhas aconselhadas	39
5.9	Regulação do cabeçal de combustão	39
5.10	Pressão da bomba e caudal de ar	39
6.	SEQUÊNCIAS DE FUNCIONAMENTO	40
7.	MANUTENÇÃO	41
8.	ANOMALÍAS / SOLUÇÕES	41

CRONO 2-L, 3-L, 5-L, 10-L, 15-L



CRONO 20-L



E Datos técnicos

Tipo CRONO		2-L	3-L	5-L	10-L	15-L	20-L
Caudal	kg/h	1,2 ÷ 2,3	1,8 ÷ 3,2	1,3 ÷ 5	4 ÷ 10	7 ÷ 15	10 ÷ 20
Potencia tórmica	kW	14,2 ÷ 27,3	21,3 ÷ 38	15 ÷ 60	47 ÷ 119	83 ÷ 178	118,5 ÷ 237
Combustible	Gasóleo, viscosidad 4 ÷ 6 mm ² /s a 20 °C:						
Alimentación eléctrica	Monofásica, ~50Hz 230V ± 10%						
Motor	0,85 A absorbidos 2750 rpm 289 rad/s			0,9 A absor. 2720 rpm 285 rad/s		1,9 A absor. 2750 rrpm 289 rad/s	2 A. absor. 2730 rpm 286 rad/s
Condensador	4 µF					6,3 µF	
Transformador de encendido	Secundario 8 kV – 16 mA						
Bomba	Presión: 8 – 15 bar						
Potencia eléctrica absorbida	0,29 kW			0,18 kW		0,385 kW	0,39 kW

GB Technical data

Type CRONO		2-L	3-L	5-L	10-L	15-L	20-L
Output	kg/h	1.2 – 2.3	1.8 – 3.2	1.3 – 5	4 – 10	7 – 15	10 – 20
Thermal power	kW	14.2 – 27.3	21.3 – 38	15 – 60	47 – 119	83 – 178	118.5 – 237
Fuel	Gas oil, viscosity 4 – 6 mm ² /s at 20 °C						
Electrical supply	Single phase, ~50Hz 230V ± 10%						
Motor	Run current 0.85 A 2750 rpm 289 rad/s			Run current 0.9 A 2720 rpm 285 rad/s		Run current 1.9 A 2750 rpm 289 rad/s	Run current 2 A 2730 rpm 286 rad/s
Capacitor	4 µF					6.3 µF	
Ignition transformer	Secondary 8 kV – 16 mA						
Pump	Pressure: 8 – 15 bar						
Absorbed electrical power	0.29 kW			0.18 kW		0.385 kW	0.39 kW

F Données techniques

Type CRONO		2-L	3-L	5-L	10-L	15-L	20-L
Débit	kg/h	1,2 ÷ 2,3	1,8 ÷ 3,2	1,3 ÷ 5	4 ÷ 10	7 ÷ 15	10 ÷ 20
Puissance thermique	kW	14,2 ÷ 27,3	21,3 ÷ 38	15 ÷ 60	47 ÷ 119	83 ÷ 178	118,5 ÷ 237
Combustible	Fioul domestique, viscosité 4 ÷ 6 mm ² /s à 20 °C						
Alimentation électrique	Monophasée, ~50Hz 230V ± 10%						
Moteur	0,85 A absorbés 2750 t/min 289 rad/s			0,9 A absorbés 2720 t/min 285 rad/s		1,9 A absorbés 2750 t/min 289 rad/s	2 A absorbés 2730 t/min 286 rad/s
Condensateur	4 µF					6,3 µF	
Transformateur d'allumage	Secondaire 8 kV – 16 mA						
Pompe	Pression: 8 – 15 bar						
Puissance électrique absorbée	0,29 kW			0,18 kW		0,385 kW	0,39 kW

D Technische Daten



Typ CRONO		2-L	3-L	5-L	10-L	15-L	20-L
Durchsatz	kg/h	1,2 ÷ 2,3	1,8 ÷ 3,2	1,3 ÷ 5	4 ÷ 10	7 ÷ 15	10 ÷ 20
Brennerleistung	kW	14,2 ÷ 27,3	21,3 ÷ 38	15 ÷ 60	47 ÷ 119	83 ÷ 178	118,5 ÷ 237
Brennstoff	Heizöl-EL, Viskosität 4 ÷ 6 mm ² /s bei 20 °C						
Stromversorgung	Einphase, ~50Hz 230 V ± 10%						
Motor		Stromaufnahme 0,85 A 2750 U/min 289 rad/s		Stromaufn. 0,9 A 2720 U/min 285 rad/s		Stromaufn. 1,9 A 2750 U/min 289 rad/s	
Kondensator		4 µF				6,3 µF	
Zündtransformator	Sekundärspannung 8 kV – 16 mA						
Pumpe	Druck: 8 – 15 bar						
Leistungsaufnahme		0,29 kW		0,18 kW		0,385 kW	
						0,39 kW	

I Dati tecnici

Tipo CRONO		2-L	3-L	5-L	10-L	15-L	20-L
Portata	kg/h	1,2 ÷ 2,3	1,8 ÷ 3,2	1,3 ÷ 5	4 ÷ 10	7 ÷ 15	10 ÷ 20
Potenza termica	kW	14,2 ÷ 27,3	21,3 ÷ 38	15 ÷ 60	47 ÷ 119	83 ÷ 178	118,5 ÷ 237
Combustibile	Gasolio, viscosità 4 ÷ 6 mm ² /s a 20 °C						
Alimentazione elettrica	Monofase, ~50Hz 230 V ± 10%						
Motore		0,85 A assorbiti 2750 g/min 289 rad/s		0,9 A assorbiti 2720 g/min 285 rad/s		1,9 A assorbiti 2750 g/min 289 rad/s	
Condensatore		4 µF				6,3 µF	
Trasformatore di accensione	Secondario 8 kV – 16 mA						
Pompa	Pressione: 8 – 15 bar						
Potenza elettrica assorbita		0,29 kW		0,18 kW		0,385 kW	
						0,39 kW	


P Dados técnicos

Tipo CRONO		2-L	3-L	5-L	10-L	15-L	20-L
Caudal	kg/h	1,2 ÷ 2,3	1,8 ÷ 3,2	1,3 ÷ 5	4 ÷ 10	7 ÷ 15	10 ÷ 20
Potência térmica	kW	14,2 ÷ 27,3	21,3 ÷ 38	15 ÷ 60	47 ÷ 119	83 ÷ 178	118,5 ÷ 237
Combustível	Gasóleo, viscosidade 4 ÷ 6 mm ² /s a 20 °C						
Alimentação eléctrica	Monofásica, ~50Hz 230 V ± 10%						
Motor		0,85 A absorvidos 2750 rpm 289 rad/s		0,9 A absor. 2720 rpm 285 rad/s		1,9 A absor. 2750 rpm 289 rad/s	
Condensador		4 µF				6,3 µF	
Transformador de ignição	Secundário 8 kV – 16 mA						
Bomba	Pressão: 8 – 15 bar						
Potência eléctrica absorvida		0,29 kW		0,18 kW		0,385 kW	
						0,39 kW	




D6275

CRONO 2-L, 3-L, 5-L, 10-L



D6276




CRONO 15-L, 20-L



D6274


Modelo / Model / Modèle Modell / Modello / Modelo	A	B	C	ØD	E	F	G	H	I	J	K	L	M
CRONO 2-L	234	254	210	90	105	211	17	180	91	75	72	130	150
CRONO 3-L	234	254	210	90	105	211	17	180	91	75	72	130	150
CRONO 5-L	234	254	210	84	112	196	4	180	91	72	72	130	150
CRONO 10-L	255	280	230	95	115	202	10	189	106	83	83	140	168
CRONO 15-L	300	345	285	123	142	228	12	213	127	99	99	160	190
CRONO 20-L	300	345	285	123	142	228	12	213	127	99	99	160	190

Presión en cámara combustión / Pressure in the combustion chamber
 Pression dans la chambre de combustion / Druck im feuerraum
 Pressione in camera di combustione / Pressão na câmara de combustão



Caudal de gasóleo / Potencia térmica
 Output / Thermal power
 Débit fioul / Puissance thermique
 Heizöldurchsatz / Brennerleistung
 Portata di gasolio / Potenza termica
 Caudal / Potência térmica

Fijación a la caldera / Fixing to the boiler / Fixation à la chaudière
 Befestigung am Kessel / Fissaggio alla caldaia / Fixação à caldeira



Alimentación del combustible / Fuel supply / Alimentation du combustible
 Brennstoffversorgung / Alimentazione del combustibile / Alimentação do combustível





Fig. / Abb. 7

CRONO 2-L, 3-L, 5-L, 10-L, 15-L

SUNTEC PUMP




- 1 - Aspiración
- 1 - Suction line
- 1 - Aspiration
- 1 - Saugleitung
- 1 - Aspirazione
- 1 - Aspiração

- 2 - Retorno
- 2 - Return line
- 2 - Retour
- 2 - Rücklaufleitung
- 2 - Dado di ritorno
- 2 - Retorno

- 3 - Tornillo by-pass
- 3 - By-pass screw
- 3 - Vis by-pass
- 3 - By-pass-Schraube
- 3 - Vite by-pass
- 3 - Parafuso by-pass

CRONO 20-L

R.B.L. PUMP



- 4 - Racord de manómetro.
- 4 - Gauge connection.
- 4 - Raccord manomètre.
- 4 - Manometeranschluß.
- 4 - Presa per il manometro.
- 4 - Racord do manómetro.


- 5 - Regulador de presión.
- 5 - Pressure adjuster.
- 5 - Régulateur de pression.
- 5 - Druckregler.
- 5 - Regolatore di pressione.
- 5 - Regulador de pressão.

- 6 - Racord de vacuómetro.
- 6 - Suction gauge connection.
- 6 - Raccord vacuomètre.
- 6 - Vakuummeteranschluß.
- 6 - Attacco vacuometro.
- 6 - Racord do vacuómetro.

- 7 - Válvula compuerta.
- 7 - Valve.
- 7 - Vanne.
- 7 - Ölmagnetventil.
- 7 - Valvola.
- 7 - Válvula de comporta.

Instalación no permitida en Alemania.
 System not permitted in germany.
 Installation pas autorisée en Allemagne.
 In Deutschland nicht zulässige Anlage.
 Impianto non ammesso in germania.
 Instalação não autorizada na Alemanha.

Fig. / Abb. 8



D6278


H m	L m	
	øi 8 mm	øi 10 mm
0,5	10	20
1	20	40
1,5	40	80
2	60	100

H = Diferencia de nivel
 H = Difference of level
 H = Différence de niveau
 H = Höhenunterschied
 H = Differenza del livello
 H = Diferença de nível

L = Longitud máxima del tubo de aspiración
 L = Max. length of suction line
 L = Longueur maxi du tube d'aspiration
 L = Max. Länge der Saugleitung
 L = Lunghezza max. del tubo di aspirazione
 L = Comprimento máxi, do tubo de aspiração


øi = Diámetro interior del tubo
 øi = Internal diameter of the oil pipes
 øi = Diamètre interne du tube
 øi = Innendurchmesser der Leitung
 øi = Diámetro interno del tubo
 øi = Diâmetro interior do tubo.

Fig. / Abb. 9



D6279

Fig. / Abb. 10



D6280

H m	L m	
	øi 8 mm	øi 10 mm
0	35	100
0,5	30	100
1	25	100
1,5	20	90
2	15	70
3	8	30
3,5	6	20

Es necesario instalar un filtro alimentación del combustible.

A filter should be installed in the fuel supply line.

Il est nécessaire d'installer un filtre d'alimentation du combustible.

Es ist notwendig, einen Filter für die Brennstoffzufuhr vorzusehen.

É necessario installare un filtro sulla tubazione di alimentazione del combustible.

É necessário instalar um filtro de alimentação de combustível.

Fig. / Abb. 11





Fig. / Abb. 12



- | | | |
|---|---|--|
| <p>E</p> <ul style="list-style-type: none"> 1 - Interruptor con fusible. 2 - Termostato seg. con rearme manual. 3 - Termostato regulación. 4 - Cuentahoras. 5 - Señalización de bloqueo a distancia. 6 - Conector macho de 7 terminales. 7 - Conector hembra de 7 terminales. 8 - Electrodo de encendido. 9 - Caja de control 553 SE. 10 - Fotoresistencia. 11 - Electroválvula. 12 - Motor. 13 - Condensador. 14 - Dispositivo precalentamiento con termostato para puesta en marcha. | <p>GB</p> <ul style="list-style-type: none"> 1 - Main switch. 2 - Limit thermostat with manual resetting. 3 - Regulating thermostat. 4 - Hours counter. 5 - Remote lock-out lamp. 6 - 7-pin plug. 7 - 7-pole socket. 8 - Ignition electrodes. 9 - Control box 553 SE. 10 - Photoresistance. 11 - Oil valve. 12 - Motor. 13 - Capacitor. 14 - Heater with start thermostat. | <p>F</p> <ul style="list-style-type: none"> 1 - Interrupteur général. 2 - Thermostat maxi. avec réarmement manuel. 3 - Thermostat de réglage. 4 - Compteur horaire. 5 - Signalisation de sécurité extérieure. 6 - Fiche 7 pôles. 7 - Prise 7 pôles. 8 - Electrodes d'allumage. 9 - Boîte de contrôle 553 SE. 10 - Cellule photorésistance. 11 - Vanne fioul. 12 - Moteur. 13 - Condensateur. 14 - Dispositif de préchauffage avec thermostat pour mise en marche. |
|---|---|--|

Fig. / Abb. 11





Fig. / Abb. 12



D

- 1 - Hauptschalter.
- 2 - Sicherheitstemperaturbegrenzer.
- 3 - Regelthermostat.
- 4 - Betriebsstundenzähler.
- 5 - Externe Störlampe.
- 6 - 7-poliger-Stecker.
- 7 - 7-poliger-Steckdose.
- 8 - Zünder Elektroden.
- 9 - Steuergerät 553SE.
- 10 - Photowiderstand.
- 11 - Ölventil.
- 12 - Motor.
- 13 - Kondensator.
- 14 - Vorwärmer mit Startfreigabethermostat.

I

- 1 - Interruttore con fusibile.
- 2 - Termostato di sicurezza con riarmo manuale.
- 3 - Termostato di regolazione.
- 4 - Contatore.
- 5 - Segnalatore di blocco a distanza.
- 6 - Connettore maschio a 7 punti.
- 7 - Connettore femmina a 7 punti.
- 8 - Elettrodi di accensione.
- 9 - Apparecchiatura 553SE.
- 10 - Fotoresistenza.
- 11 - Elettrovalvola.
- 12 - Motore.
- 13 - Condensatore.
- 14 - Riscaldatore con termostato di consenso all'avviamento.


P

- 1 - Interruptor com fusível.
- 2 - Termostato de segurança com rearme manual.
- 3 - Termostato de regulação.
- 4 - Conta horas de serviço.
- 5 - Sinalização de bloqueio à distância.
- 6 - Conector macho de 7 terminais.
- 7 - Conector fêmea de 7 terminais.
- 8 - Eléctrodos de ignição.
- 9 - Caixa de controle 553SE.
- 10 - Fotorresistência.
- 11 - Electroválvula.
- 12 - Motor
- 13 - Condensador.
- 14 - Dispositivo de préaquecimento com termostato para entrada em funcionamento.

Regulación de los electrodos / Electrodes settings / Réglage des électrodes
 Elektrodeneinstellung / Regolazione elettrodi / Regulação dos eléctodos

Fig. / Abb. 13

CRONO 2-L & 3-L



ATENCIÓN:

Deben respetarse estas distancias.

WARNING:

Measurements must be respected.


ATTENTION:

Les distances doivent être respectées.

ACHTUNG:

Diese Abstände müssen eingehalten werden.

CRONO 5-L




ATTENZIONE:

Le misure indicate devono essere rispettate.


ATENÇÃO:

Devem respeitar-se estas distâncias.

CRONO 10-L



CRONO 15-L & 20-L



Modelo quemador Burner model Modèle brûleur Brennermodell Modello bruciatore Modelo queimador	Boquilla Nozzle Gicleur Düse Ugello Boquilha		Presión bomba Pump pressure Pression pompe Pumpendruck Press. pompa Pressão bomba	Caudal Burner output Débit brûleur Durchsatz Portata Caudal	Regulación cabezal combustión Combustion head adjustment Réglage tête de combustion Brennerkopfeinstellung Regolazione testa di combustione Regulação cabeçal combustão	Regulación registro del aire Air damper adjustment Réglage volet d'air Luftklappeneinstellung Regolazione serranda Regulação registo de ar	
	GPH	Angulo Angle Angle Winkel Angolo Ângulo	Tipo Type Type Typ Tipo	bar	kg/h ±4%	Indice Set-point Index Raste Tacca índice	Indice Set-point Index Raste Tacca índice
CRONO 2-L	0,30	80°	W-B	13	1,2	fijo, índice 2 / fix, set-point 2 fixe, index 2 / fest, Raste 2 tacca fissa 2 / fixa índice 2	0,1
	0,40	60°	W-B	12	1,5		0,3
	0,50	60°	W-B	12	1,9		0,9
	0,60	60°	W-B	12	2,3		3,5
CRONO 3-L	0,50	60°	W-B	12	1,9	fijo, índice 2 / fix, Set-point 2 fixe, index 2 / fest, Raste 2 tacca fissa 2 / fixa índice 2	0,7
	0,60	60°	W-B	12	2,3		1,0
	0,65	60°	W-B	12	2,5		2,6
	0,75	60°	W-B	12	2,9		4,9
	0,75	60°	W-B	14	3,2		5,8
CRONO 5-L	0,40	80°/60°	W-B	10	1,3	0,5	0,1
	0,50	60°	W-B	12	1,9	1,0	1,2
	0,60	60°	W-B	12	2,3	1,5	2,4
	0,65	60°	W-B	12	2,5	2,0	2,9
	0,75	60°	W-B	12	2,9	3,0	3,5
	0,85	60°	W-B	12	3,3	3,5	4,2
	1,00	60°/45°	W-B	12	3,8	4,5	5,1
	1,10	60°/45°	W-B	12	4,2	5,5	5,6
	1,25	60°/45°	W-B	12	4,8	6,0	6,3
	1,25	60°/45°	W-B	13	5,0	6,0	6,7
CRONO 10-L	1,00	60°	W-B	12	4,0	0	0,9
	1,10	60°	W-B	12	4,4	1	3,1
	1,25	60°	W-B	12	5,0	2	3,4
	1,50	60°	W-B	12	6,0	3	3,8
	1,75	60°	B	12	7,0	4	4,5
	2,00	60°	B	12	8,0	5	4,9
	2,25	60°	B	14	9,8	6	6,0
CRONO 15-L	1,75	60°	W-B	12	7,0	0	1,3
	2,00	60°	W-B	12	8,0	1	2,3
	2,25	60°	W-B	12	9,0	3	2,6
	2,50	60°	W-B	12	10,0	3,5	3,0
	3,00	60°	B	12	12,0	5	3,5
	3,50	60°	B	12	14,0	6	4,4
	3,50	60°	B	14	15,2	6	5,6

Fig. / Abb. 14





Fig. / Abb. 15



A

Enroscar justo a tope
Anziehen, ohne bis zum anschlag auszufahren
Tighten without moving backwards to the end
Serrer, mais pas jusqu'a la butée
Serrare senza portare a battuta
Não apertar a fundo

S7637

CRONO 20-L

Boquilla Nozzle Gicleur Düse Ugello Boquilha			Presión bomba Pump pressure Pression pompe Pumpendruck Pressione pompa Pressão bomba	Caudal Burner output Débit brûleur Durchsatz Portata Caudal	Regulación cabezal combustión Combustion head adjustment Réglage tête de combustion Brennerkopfeinstellung Regolazione testa di combustione Regulação cabeçal combustão	Regulación registro del aire Air damper adjustment Réglage volet d'air Luftklappeneinstellung Regolazione serranda Regulação registo de ar	
GPH	Angulo Angle Angle Winkel Angolo Ângulo	Tipo Type Type Typ Tipo	bar	kg/h ±4%	Indice Set-point Index Raste Tacca índice	Llama pequeña Low-flame Petite flamme Kleine Flamme Piccola fiamma Chama pequena	Llama grande High-flame Grande flamme Grosse Flamme Grande fiamma Chama grande
						Indice Set-point Index Raste Tacca índice	Indice Set-point Index Raste Tacca índice
2,50	60°	W	12	10	0,0	0,2	1,4
3,00	60°	W	12	12	1,0	0,4	2,1
3,50	60°	B	12	14	2,5	0,7	3,0
4,00	60°	B	12	16,1	4,0	0,9	3,5
4,50	60°	B	12	18,1	6,0	1,4	4,5
4,50	60°	B	14	20	6,0	1,4	6,0

Fig. / Abb. 16





Fig. / Abb. 17



B

Enroscar justo a tope
Anziehen, ohne bis zum anschlag auszufahren
Tighten without moving backwards to the end
Serrer, mais pas jusqu'a la butée
Serrare senza portare a battuta
Não apertar a fundo

Fig. / Abb. 18





Fig. / Abb. 19



1. MAIN FEATURES

- The burner meets protection level of IP 40, EN 60529-
- Burner with CE marking in conformity with EEC directives: EMC 89/336/EEC, Low Voltage 73/23/EEC, Machines 98/37/EEC and Efficiency 92/42/EEC.

2. BURNER DESCRIPTION

(Fig. 1, page 3)

One stage gas oil burner.

1. Oil pump
2. Control-box
3. Reset button with lock-out lamp
4. Flange with insulating gasket
5. Air damper adjustment
6. Nozzle holder assembly
7. Photoresistance
8. Hydraulic jack
9. Start delaying device

2.1 Burner equipment

Flange with insulating gasket	1
Screw and nuts for flange.	1
Screw and nuts for flange to be fixed to boiler	2 or 4
Flexible oil pipes with nipples	2

3. TECHNICAL DATA

- 3.1 Technical data** (Page 4)
- 3.2 Overall dimensions** (Page 6)
- 3.3 Working fields** (Page 7)

4. INSTALLATION

4.1 Boiler fixing (Page 8)

- Put on the flange (1) the screw and two nuts, (see fig. 3).
- Widen, if necessary, the insulating gasket holes (5), (see fig. 4).
- Fix the flange (1) to the boiler door (4) using screws (2) and (if necessary) the nuts (3) interposing the insulating gasket (5), (see fig. 2).
- For CRONO 10-L, 15-L and 20-L burners, after installation check that the burners are slightly tilted forward, as shown in fig. 5.

4.2 Fuel supply (Page 8)

The burner is designed to allow entry of the oil supply pipes on either side.
Depending on the oil supply pipes position (to the right or to the left hand side of the burner) the fixing plate (1) and closing plate (2) should be reversed, (see fig. 6).

4.3 Hydraulic systems (Page 9 and 10)

Warning:

- The pump is designed to allow working with two pipes. In order to obtain one pipe working it is necessary to unscrew the return plug or the connector (2), remove the by-pass screw (3) and then tighten the plug or the connector (2). (See fig. 7).
- Before starting the burner make sure that the return pipe-line is not clogged. An excessive back pressure would cause damage to the pump seal.

Priming pump (Page 8)

On the system in fig. 6 it is sufficient to loosen the suction gauge connection (6, fig.7, pag. 9) and wait until oil flows out.

On the systems in fig. 9 and 10 start the burner and wait for the priming. Should lock-out occur prior to the arrival of the fuel, await at least 20 seconds before repeating the operation. The pump suction should not exceed a maximum of 0.4 bar (30 cm Hg). Beyond this limit gas is released from the oil. Oil pipes must be completely tight.

In the vacuum systems (fig. 10) the return line should terminate within the oil tank at the same level as the suction line. In this case a non-return valve is not required. Should however the return line arrive over the fuel level, a non-return valve is required. This solution however is less safe than previous one, due to the possibility of leakage of the valve.

4.4 Electrical wiring (Fig. 11, pag. 11 and 12)

Attention:

Do not exchange neutral with phase.

Notes:

- Wires of 1 mm² section.
- The electrical wiring carried out by the installer must be in compliance with the rules in force in the Country.

Testing:

Check the shut-down of the burner by opening the thermostats and the lock-out by darkening the photoresistance.

Control box

To remove the control-box from the burner, loosen screw (A, fig. 12, page 11 or 12) and pull to the arrow direction, after removing all components, the 7 pin plug and earth wire.

In case of disassembly of the control box, retighten the screw (A) with a torque wrench setting of 1 – 1.2 Nm.

4.5 Electrodes settings (Page 13)

To have access to the electrodes carry out operations as described in chapter “5.2 or 5.8 Recommended nozzles”.

Lean the diffuser disc-holder assembly (1) on the nozzle-holder (2) and lock it with screw (3).

For prospective adjustments of the electrodes assembly (4), loosen screw (5), (see fig. 13).

5. WORKING

BURNERS CRONO 2 - 3 - 5 - 10 e 15-L

5.1 Combustion adjustment.

In conformity with Efficiency Directive 92/42/EEC the application of the burner on the boiler, adjustment and testing must be carried out observing the instruction manual of the boiler, including verification of the CO and CO₂ concentration in the flue gases, their temperatures and the average temperature of the water in the boiler.

To suit the required appliance output, choose the proper nozzle and adjust the pump pressure, the setting of the combustion head, and the air damper opening in accordance with the following schedule at page 14.

The values shown in the table refer to 12.5% CO₂ at sea level and with light oil and room temperature of 20 °C.

5.2 Recommended nozzles :

Delavan type W-B.

**To fit the nozzles, proceed as follows:
(See fig. 14, page 15)**

- Remove nozzle-holder assembly (1) after loosening screws (2) and nut (3), remove the small cables (4) from the control box, the photoresistance (6) and the socket (10) for CRONO 2-L, 3-L and 5-L burners.
- Withdraw the small cables (4) from the electrodes, remove the diffuser disc-holder assembly (11) from the nozzle-holder assembly (1) after loosening screw (3, fig. 13, page 13).
- Screw the nozzle (12) correctly and tighten it as shown in the figure.

Attention:

During reassembly of the nozzle-holder assembly screw the nut (3) as shown in figure 15, page 15.

5.3 Pump pressure

The pump leaves the factory set at 12 bar.

To change it act on pump pressure adjust screw (5, fig. 7, page 9).

5.4 Combustion head setting

(CRONO 5-L, 10-L e 15-L) (Fig. 14, page 15)

It depends on the output of the burner and is carried out by rotating the setting screw (5) clockwise or anti-clockwise until the set-point marked on the regulating rod (9) is level with the outside plane of the nozzle-holder assembly (1).

– In the sketch the combustion head is set for an output of 0.85 GPH at 12 bar (bruciatore CRONO 5-L).

The set-point 3 of the regulating rod (9) is at the same level with the outside plane of the nozzle-holder assembly (1) as shown in the schedule pag. 14.

5.5 Air damper adjustment (Fig. 14, page 15)

- To vary the setting adjust the screw (7) after loosening the nut (8).
- When the burner shuts down the air damper automatically closes until a max. chimney depression of 0.5 mbar.

5.6 Fuel heating

(CRONO 2-L, 3-L e 5-L)

In order to assure regular ignition and working also at low temperature the burner has an oil pre-heater fitted in combustion head. The pre-heater starts when thermostats close.

When the required temperature for ignition is reached the thermostat fitted on the nozzle holder starts the burner.

The pre heater remains energised during working and cuts out when the burner shuts-down.

BURNER CRONO 20-L

5.7 Combustion adjustment.

In conformity with Efficiency Directive 92/42/EEC the application of the burner on the boiler, adjustment and testing must be carried out observing the instruction manual of the boiler, including verification of the CO and CO₂ concentration in the flue gases, their temperatures and the average temperature of the water in the boiler.

To suit the required appliance output, choose the proper nozzle and adjust the pump pressure, the setting of the combustion head, and the air damper opening in accordance with the following schedule at page 15.

The values shown in the table refer to 12.5% CO₂ at sea level and with light oil and room temperature of 20 °C.

5.8 Recommended nozzles :

Delavan type W-B.

**To fit the nozzles, proceed as follows:
(See Fig. 16, page 16)**

- Remove nozzle-holder assembly (1) after loosening screws (2) and nut (3), remove the small cables (4) from the control box and the photoresistance (5).
- Withdraw the small cables (4) from the electrodes, remove the diffuser disc-holder assembly (8) from the nozzle-holder assembly (1) after loosening screw (3, fig. 13, page 13).
- Screw the nozzle (9) correctly and tighten it as shown in the figure.

Attention:

During reassembly of the nozzle-holder assembly screw the nut (3) as shown in figure 17, page 16.

5.9 Combustion head setting (Fig. 16, page 16)

It depends on the output of the burner and is carried out by rotating the setting screw (6) clockwise or anti-clockwise until the set-point marked on the regulating rod (7) is level with the outside plane of the nozzle-holder assembly (1).

– In the sketch the combustion head is set for an output of 0.85 GPH at 12 bar. The set-point 2.5 of the regulating rod (7) is at the same level with the outside plane of the nozzle-holder assembly (1) as shown in the schedule pag. 15.

5.10 Pump pressure and air output

The burner, in order to guarantee good smooth starts, irrespective of the type of boiler, is fitted with a hydraulic device which, independently of the control-box, reduces the fuel- and air-flow.

At ignition, the pressure at the nozzle is 9 bar.

After 3 - 9 seconds, it automatically increases to 12 bar.

The air-flow, initially adjusted to the low setting, is, at the change-over of pressure, automatically brought to the air-flow required for the big flame.

■ SETTING FOR THE LOW IGNITION-FLAME

Adjustment of air shutter (Fig. 18, page 16)

Unloosen the screw (8), by approximately one full turn; in this way, the burner remains permanently on low flame.

Unloosen the nut (5), turn the screw (4) until the indicator (6) reaches the position desired. Then lock the nut (5) and tighten the screw (8).

Adjustment start delaying device (Fig. 18, page 16)

This is set at 9 bar in the factory.

The pressure gauge must be mounted in place of plug (4, fig. 7, page 9). Should it be necessary to re-set or alter such pressure, this can be done, by adjusting screw (7), always after having loosened screw (8).

■ HIGH-FLAME SETTING

Air-damper adjustment (Fig. 19, page 16)

Loosen the nut (3), turn the screw (1), until the indicator (2) is in the required position. Then, lock the nut (3).

Pump-adjustment: (Fig. 7, page 9)



This is set in 12 bar in the factory.

The pressure gauge must be mounted in place of plug (4). Should it be necessary to re-set or alter such pressure, this can be done, by adjusting screw (5).



When the burner shuts down the air damper automatically closes until a max. chimney depression of 0.5 mbar.

6. BURNER START-UP CYCLE



CRONO 2-L, 3-L, 5-L



CRONO 10-L, 15-L



CRONO 20-L



C Lock out is indicated by a lamp on the control box (3, fig. 1, page 3).

7. MAINTENANCE

The burner requires a periodic maintenance carried out by a qualified and authorized technician.

Maintenance is essential for the reliability of the burner, avoiding the excessive consumption of fuel and consequent pollution.

Before carrying out any cleaning or control always first switch off the electrical supply to the burner acting on the main switch of the system.

The basic checks are:

- Check that there are no obstructions or dents in the supply or return oil pipes.
- Clean the filter in the oil suction line and in the pump.
- Clean the photoresistance, (7, fig. 1, page 3).

- Check for correct fuel consumption.
- Replace the nozzle and check the correct position of electrodes (fig. 13, page 13).
- Clean the combustion head in the fuel exit area, on the diffuser disc.
- Leave the burner working without interruptions for 10 min. and correctly set all the components stated in this manual. Then carry out a combustion check verifying:
 - Smoke temperature at the chimney.
 - Content of CO₂ (%).
 - Content of CO (ppm).
 - Smoke value according to opacity smoke index according to Bacharach scale.

8. FAULTS / SOLUTIONS

Here below you can find some causes and the possible solutions for some problems that could cause a failure to start or a bad working of the burner. A fault usually makes the lock-out lamp light which is situated inside the reset button of the control box (3, fig. 1, page 3). When lock out lamp lights the burner will attempt to light only after pushing the reset button. After this if the burner functions correctly, the lock-out can be attributed to a temporary fault.

If however the lock out continues the cause must be determined and the solution found.

FAULTS	POSSIBLE CAUSES	SOLUTION
The burner will not start when the adjustment thermostat closes.	Lack of electrical supply.	Check presence of voltage in the L1 - N clamps of the 7 pin plug.
		Check the conditions of the fuses.
		Check that the thermostat limit is not locked out.
	The photoresistance sees false light.	Eliminate the light.
	Heater or start thermostats are faulty. (CRONO 2-L, 3-L and 5-L)	Replace them.
Burner runs normally in the prepurge and ignition cycle and locks out after 5 seconds ca.	The connections in the control box are wrongly inserted.	Check and completely connect all the plugs.
	The photoresistance is dirty.	Clear it.
	The photoresistance is defective.	Change it.
	Flame moves away or fails.	Check fuel pressure and output.
		Check air output.
Change nozzle.		
Check the solenoid valve coil.		
Burner starts with an ignition delay.	The ignition electrodes are wrongly positioned.	Adjust them according to the instructions of this manual.
	Air output is too high.	Set the air output according to the instructions of this manual.
	Nozzle dirty or worn.	Replace it.

Warning

The manufacturer cannot accept responsibility for any damage to persons, animals or property due to error in installation or in the burner adjustment, or due to improper or unreasonable use or non observance of the technical instruction enclosed with the burner, or due to the intervention of unqualified personnel.

Baxi Calefacción, S.L.U.

Salvador Espriu, 9 | 08908 L'Hospitalet de Llobregat | Barcelona
T. 93 263 0009 | TF. 93 263 4633 | www.baxicalefaccion.com

A BAXI GROUP company